



Bolt colour

Below is the procedure to change colour of bolts.


1. Open view properties




2. Click on representation




3. Define a object group for example below i chose bolt of size 20 mm




4. For the object group bolt define colour by attribute
Choose bolt comment as below





5. You should have the object representation as below & click apply ok.



6. Enter the value of class in bolt comment & click modify.
7. Below are examples of different class entered in bolt comment.

